

SLURRY INSTRUCTIONS

WARNING



Protect your head and all exposed skin when mixing and pouring this epoxy slurry.

A - Get all **Epoxy Slurry** materials and tools together. Ensure surfaces inside and outside of the slurry pour channel and surrounding walls are clean of debris and **COMPLETELY DRY!** Also ensure that the bottom edge of the sump body that will be inserted into the channel has been **abraded 2" up from the cut edge inside and outside.**



B - Open the large can containing the slurry mixture. Dry structural sand is present at the very bottom of the slurry mixture. Attach the provided steel stator mixer to a powered drill and carefully break up the dry contents at the bottom and mix the slurry until it is smooth and consistent and no sand is at the bottom.



C - Do not open or handle hardener without gloves and face protection. Pour all the hardener into the mixed slurry can. Mix thoroughly for at least 1 min.

D - When mixed the slurry will be slightly thinner and easier to pour. Pour the slurry from the metal can into the provided blue bucket.

E - Using the flexible blue bucket, pour the epoxy slurry evenly into each channel length and allow it to self level. When you pour it, it will flow outwards. Continue to pour more slurry where it appears low.

F - With all of the epoxy slurry level in the channel, carefully and evenly lower the clean, abraded bottom edge of the sump body into the channel. Do not drop it in.

